
PURPOSE

This section provides information on the Surface preparation of fibreglass – new and old. Removal of release agents, and filling imperfections.

INTRODUCTION

Fibreglass, polyester reinforced with chopped or woven glass fibre, is used extensively in the boat building industry. A well maintained fibreglass boat, in the absence of osmotic blistering can last a long time. In all cases, correct surface preparation is essential for optimum performance.

GENERAL ASPECTS

New Fibreglass

In the case of newly made fibreglass boats, mould release agents are used by manufacturers to remove fibreglass hulls from moulds. The presence of mould release agents or grease is indicated if water forms droplets on the hull instead of an even film. These contaminants are detrimental to the adhesion of a coating system. They must be removed prior to any other surface preparation using a suitable wax and grease remover.

Old Fibreglass

The removal of all oil, grease, fat and other contaminants is essential prior to any other surface preparation. In most cases, the existing coating system will need to be removed entirely to ensure a sound base for the new system.

SURFACE PREPARATION

To ensure good adhesion and long term performance of any coating for fibreglass, it is essential that the correct type of surface preparation is carried out. The removal of chemicals, oil, grease and fat must be completed before any other preparation work commences.

Removal of Release Agents

The mould release agents and other contaminants can be removed by degreasing, using commercially available biodegradable degreasing solution. After cleaning, the surface should be flushed thoroughly with copious quantities of clean, fresh water. If the water spreads evenly over the surface of the hull the surface is clean.

Filling Imperfections

Imperfections should be addressed using the following method:

- Abrade the surface thoroughly to a dull matt finish with P80 grit paper, wash with clean, fresh water.
- Prime the surface. Allow to dry. Refer to relevant data sheets.
- Fill the primed imperfections with SeaPro EFC (epoxy fairing compound) to remove the imperfection.
- Sand the SeaPro EFC (epoxy fairing compound) to give a smooth, even finish.
- Overcoat with the appropriate Primer or Undercoat.

Abrasive Blast Cleaning

The surface of the fibreglass hull can be sweep blasted using a non-metallic grit such as ilmenite, bicarbonate soda or garnet. The surface should be washed clean after blasting using clean, fresh water to remove any dust or loose materials. The dust and spent abrasive must be thoroughly removed after blasting. Care must be taken to avoid damage to or removal of gelcoat. Where gelcoat is damaged or removed a high build epoxy coating system must be used to protect hulls from osmosis.



Quality
ISO 9001

Valspar is committed to quality in the design, production and delivery of its products and services. Valspar's Australian manufacturing facilities quality management systems are certified to ISO9001.

Valspar's laboratory facilities are accredited for technical competence with the National Association of Tests Authorities, Australia (NATA) and comply with the requirements of ISO/IEC 17025. Accreditation No.104 (Footscray), 166 (Blacktown), 1154 (Glendenning) and 931 (Kilburn).



For the most up to date information contact Valspar Customer Service Hotline or visit the Wattyl Website.

CUSTOMER SERVICE HOTLINE	Australia	New Zealand
WEBSITE	132 101	0800 735 551
	www.wattylpc.com	www.wattylpc.com

Trademarks are the property of Valspar Paint (Australia) Pty Ltd.

1. This information, provided by Valspar Paint (Australia) Pty Ltd (hereinafter referred to as "Valspar"), is important to ensure that the listed product(s) perform according to the stated application and uses and must be followed to meet Valspar's warranties express and implied. Valspar advises that you (a) review the Technical Data Sheets (TDS) and Material Safety Data Sheets (MSDS) before you use or handle the product; (b) ensure that the product be used only in accordance with the information provided by Valspar and the product(s) be transported, stored and handled in accordance with the information on the MSDS and relevant TDS; and (c) thoroughly test the product, using the recommended application method on a sample of intended substrate, before using the product. 2. The information in this TDS was prepared using information gathered during product development. While Valspar endeavours to update this information and maintain the accuracy and currency of its contents, Valspar does not warrant that the information provided is current when the product is used or is wholly comprehensive. 3. For all product and non-product related information, Valspar recommends that you conduct such additional investigations as may be necessary to satisfy yourself of the accuracy, currency and comprehensiveness of the information on which you rely in using and handling the product. If you require further information please contact your nearest Valspar office before using the product(s). 4. To the full extent permitted by law, Valspar's liability for breach of a condition or warranty implied into the contract for sale between Valspar and you by law is limited at Valspar's election to: (a) the replacement of the product; or (b) payment of the cost of replacing the product. If coating rectification is required Valspar Technical Services shall be contacted prior to commencement. VALSPAR PAINT (AUSTRALIA) PTY LTD (ABN 40 000 035 914)